

Carry out replacement in the following order:

1

Tighten the parking brake lever.

2

Place wedge blocks under the rear wheels.

3



Loosen the wheel mounting bolts.

4

Raise the front of the car and secure on supports.

5




Remove the front wheels.

6.1



Disconnect the wiring and the brake hose from the bracket on the shock strut.

6.2



7.1



Unscrew the bolt and remove the steering knuckle from the damper strut.

7.2



7.3



8



Unscrew the three fastening nuts of the suspension strut mount.

9



Remove the suspension strut.

10



Set a spring compressor and compress the spring

AutoDoc recommends:

Note that when using a spring compressor, spring coils need to be securely gripped, compressing the spring on the opposite sides.

Ensure the correct position of the spring in the retainer.

Make sure that the spring coils tightly entered the lock handles.

11



Unscrew the top fastening of the shock strut mount.

12



Remove the top strut mount.

13



Install a new strut mount

14



Secure the top strut mount with bolts to the car body

15



Place the shock absorber in the wheel arch and secure it

16



Screw the three fastening nuts of the shock strut mount

17.1



Fix the shock absorber strut on the steering knuckle.


17.2



17.3



18.1



Connect the wiring and the brake hose to the bracket on the shock strut.

18.2



19



Install the wheel.

20



Lower the car and working in a cross order,
tighten the wheel bolts

We hope that this information
have been useful for you!

[Video tutorials](#)

Watch our detailed video guides about your BMW 3 E36 repair on our youtube channel. Watch video guides.

[AutoDoc online](#)

Highest quality suspension strut mounts for your car BMW 3 E36 are available on AutoDoc. Go to the website.

AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

QUALITY AUTO PARTS



BMW



SUSPENSION STRUT MOUNTS



BMW 3 E36



SUSPENSION STRUT MOUNTS FOR BMW



SUSPENSION STRUT MOUNTS FOR BMW 3 E36



i Disclaimer:

The document contains only general recommendations that may be useful for you when you perform repair or replacement works. AutoDoc shall not be liable for any loss, injury, damage of property, acquired in the repair or replacement process due to incorrect usage or misinterpretation of the provided information.

AutoDoc shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for informative purposes only and cannot replace advice from specialists.

AutoDoc shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AutoDoc strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

AUTODOC IN SOCIAL MEDIA

